


Installation


Step 1: Bracket/Box Installation

Wall Mounting


With 86 embedded box in the wall




Without 86 embedded box in the wall



Step 2: Back cover Installation



Application Network Topology



IP Announcement

1. While R20A starts up normally, hold the call button for several seconds after the Status LED turns blue, voice system will enter IP announcement mode.
2. In announcement mode, the IP address will be announced periodically.
3. Press Call Button again to quit the announcement mode.
4. In announcement mode, phone announces "IP 0.0.0.0" if no IP address is gained.

Configuration

1. Access the Web UI: Input the IP address into web browser to configure the phone.
2. Account Registration: On web UI, go to the path: **Account -> Basic** page Register Account and fill in the account information. (*Please refer to user manual for more information*)
3. Configure the Push Button: On web UI, go to the path: **Intercom -> Basic -> Push Button** to configure the call number.
4. Configure the code to open the relay: On web UI, go to the path: **Intercom -> Relay -> Relay ID/DTMF** and choose the DTMF code number in corresponding area.

Operation

- Make a call:**
1. Press the call button to call indoor SIP Phone.
 2. During the talk, called party can press pre-configured code number to unlock the door.
- Receive a call:**
R20A supports Auto Answer by default. Incoming call will be answered automatically.

Indicators

Name	Status	Description
Status indicator	Blue	Normal status
	Red	Calling
	Red	Restarting
	Red	Network is unavailable
Green	Green	Initialing/Talking on a call
	Green	Receiving a call
Red/Blue	Red/Blue	Firmware upgrading

Note: For more LED settings, please refer to R20 webUI: Intercom -> LED Setting.

Notice Information

Akuvox R20A firmware contains third-party open source software under the terms of the GNU General Public License (GPL). Akuvox is committed to meeting the requirements of the GNU General Public License (GPL) and will make all required source code available.

The source code of software under the terms of GNU GPL can be downloaded online: <http://www.akuvox.com/gpl>.

Information contained in this document is believed to be accurate and reliable at the time of printing. This document is subject to change without notice, any update to this document can be viewed on Akuvox's website: <http://www.akuvox.com> © Copyright 2019 Akuvox Ltd. All rights reserved.



Unpacking

- Please make sure the package contains the following items:
- Universal Accessories:**
- R20A x 1
 - Back cover x 1
 - M2.5x6 screw x 6
 - ST4x20 screw x 4
 - Screw fixing seat x 4
 - Rope x 1
 - Allen Wrench x 1
 - Cable locking plate x 1
 - M3x6 screw x 2
 - M4x30 screw x 2
 - Wall-mounting bracket x 1
 - Rubber Plug x 3 (S,M,L)
 - Wall-mounting screw x 4

Product Overview

