

Pro-X Doorbell

LXDB4I-WIFIKT

LXDB4I-WIFI (doorbell)

LXDBCM-WIFI (chime)





FAQ

- **Can I connect multiple chimes to a doorbell?**
 - Yes
 - How many? **unlimited*
- **Can I connect multiple doorbells to a chime?**
 - Yes
 - How many? **unlimited*
- **Can I have a mix of doorbells and chimes all interconnected with each other?**
 - In theory yes, *but why?*
- **Can I add the doorbell to my Pro-X NVR? Platinum?**
 - Yes, and yes as ONVIF
- **Does this have an SD card slot?**
 - MicroSD yes, up to 256GB
- **Are there VCAs?**
 - Only MD2.0, no line crossings, intrusion, etc.
- **Will this doorbell work with my existing mechanical or non Pro-X electrical chime?**
 - No, and you may require a jumper (included) to be put on your mechanical chime.
- **Is this doorbell compatible with X-Station?**
 - Not all the doorbell features will work with X-Station.
 - Answering the door, Two-way Audio through NVR



LED Indicators

Video Doorbell	Wireless Chime	Description
Solid Blue	Solid Green	Device is operating normally and network is functioning properly
Flashing Blue (quickly)	Flashing Green (quickly)	- The device is connecting to the network - The doorbell is ringing
Flashing Blue (slow)	Flashing Green (slow)	- Device is in network configuration - Someone is answering the call from doorbell
Flashing Blue and Red	Flashing Green and Red	The device firmware is being upgraded
Solid Red		The device is starting up or there is a malfunction
Flashing Red		The device is unable to connect to the network



Doorbell Setup

- Have a registered Pro-X Next account (its free, no subscription)
- Ensure Bluetooth is enabled on the mobile device and working WIFI connection.





- On initial power and activation, doorbell will automatically enter Bluetooth pairing mode – there will be an audible sound to indicate this as well.



Doorbell Setup



- Just like many Pro-X products, use Pro-X Next to scan the QR code to add the device to the app.





Doorbell Setup



- On successful scan and add





Doorbell Setup

- Continue following the activation/ setup guide from Pro-X Next





Doorbell Setup

- When the doorbell is detected with Pro-X Next, complete the registration process.

3:54 5G+

< Add Device

To ensure the security of your device, please set the device password.

Username admin

Password

Email Enter for password reset



Next

- Adding an email address is optional but may greatly assist in password reset operations.



Doorbell Setup



- Next, we will add the doorbell to our wifi network.





Doorbell Setup



- We're almost complete with the Doorbell.





Doorbell Setup

- Final step, configure the time and doorbell is ready to view





Chime Setup

- The steps to add the chime to Pro-X Next are very similar to the doorbell. For that we will not go over this process.





Notes

- There is a 30 second 'cool down' period where pressing the doorbell will stop:
 - Doorbell ringing
 - Chime ringing
 - New Pro-X Next calling notifications
- Retested MD for ONVIF, confirmed this to be working on Platinum and ODM
- Jumper cables – needed or not needed?
 - It depends, if you want to ensure no power drops, can use the jumper; alternative is removing the chime from the wiring.