


# Turret Network Camera

## Quick Installation Guide




No.	Description	No.	Description
1	Trim Ring	7	Audio Output
2	Enclosure	8	1-ch Alarm Input and 1-ch Alarm Output
3	Mounting Base	9	RST (Reset) Button
4	Camera	10	Memory Card Slot
5	Power Cord	11	MIC
6	10M/100M Self-adaptive Ethernet Interface		

## Ceiling Mounting

### Steps:

#### 1. Disassemble the camera.

- 1). Rotate the trim ring anticlockwise to take it off from the camera.
- 2). Rotate the mounting base anticlockwise to take it off from the camera.
- 3). Separate the camera and the enclosure.




#### 2. Install the memory card.

- 1). Find the Micro SD/RST cover on the side of the camera.




- 2). Take off the cover and insert the microSD card into the card slot.




- 3). Place the cover back.

3. Stick the drill template on the installation place and drill the screw holes and the cable hole on the ceiling according to the drill template.




4. Fix the mounting base to the ceiling with two supplied expansion screws.




5. Connect the corresponding power/network cable.


6. Install the camera along with the enclosure to the mounting base by anticlockwise rotating the camera.



7. Rotate the enclosure to adjust the pan angle; rotate the camera to adjust the tilt angle.



8. Attach the trim ring to the camera and rotate the trim ring clockwise to get it secured.



### FCC WARNING

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help. To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum distance between 20cm the radiator your body: Use only the supplied antenna.

## Reset and Restore Camera

Press **Reset** button for about 10s when the camera is powering on or rebooting to restore the default settings, including the user name, password, IP address, port No., etc.

For the position of the reset button, refer to the figure in the interface introduction page.